



Chillez.
POOLS, FIRE & ICE TUBS



Welcome to Chillzz

Thank you for choosing Chillzz – the modern, minimalist stock tank pool designed for comfort, style, and easy installation. Whether you're setting up for a private garden escape or a guest-ready terrace in your local stay, your Chillzz pool is built to last and easy to maintain.



What's Included

Your Chillzz Stock Tank Pool includes:

- Galvanized steel tub (round or oval)
- Drainage plug
- Pre-drilled holes
- Inlet & outlet ports for filter installation
- Sandfilter pump and hoses



Before installing your pool:

- Ensure a flat and level surface (preferably concrete, stone, or compacted gravel).
- Avoid placing on soft soil or wooden decking without reinforcement.
- Ensure easy access to water and drainage.
-

Note: If placing on a rooftop/terrace, confirm weight-bearing capacity with your contractor or engineer.

1. Installing the Inlet and Outlet Connectors:

Install the inlet and outlet fittings into the pre-drilled (or custom-drilled) holes on the stock tank.

- The inlet with the strainer (grid/raster) should be installed in the lower hole — this is the water intake.
- The inlet with the jet nozzle should be installed in the upper hole — this is the water return.

Important: Ensure the rubber sealing ring is placed on the inside of the tub/pool to prevent leaks.

Once the fittings are in place:

- Attach the valves to both inlets.
- Connect the hose adaptors (compatible with both 32mm and 38mm hoses) to the fittings.

Make sure all connections are tightened securely, but avoid over-tightening to prevent damaging the seals.



2. Installing the Sand Filter Pump

For detailed instructions, please refer to the manufacturer's manual included with the pump. Below is a summary of the most important steps and tips:

- We recommend using sand as the filter medium, rather than filter balls or cartridges. Sand is more durable, requires less frequent cleaning, and is easier to maintain over time.
- When attaching the locking ring around the filter pump:
 - Place the ring in position, then gently tap it into place using a rubber mallet or similar tool.
 - Tighten the screw slightly, then tap again around the ring to ensure an even seal.
 - Continue alternating between tapping and tightening until the ring is securely locked.



3. Connecting the Filter Pump to the tub

- Connect the lower outlet on the stock tank to the inlet (suction) port on the filter pump.
- Connect the upper outlet on the stock tank to the outlet (return) port on the filter pump.

Ensure all connections are tight and secure to prevent leaks.



NOTE:

- Make sure the valves on the pool are open to circulate the water
- Never change the function valve while the filter pump is running
- Make sure there are no leaks
- Check the pressure on the filter pump
- Read the instructions from the manufacturer

Please send us an email if you have any doubts.

Before you turn on the filter pump, open the valve on the bottom (see red circle) and let out the air so the water can be pumped in to the filter.

Chillzz.

POOLS, FIRE & ICE TUBS

Exclusive distributor in Europe

WWW.CHILLZZ.EU



stocktanks@chillzz.eu



+351 926 564 335

+32 493 19 96 56



[@chillzz.eu](https://www.instagram.com/chillzz.eu)